### Introduction to Diffusion-weighted Imaging

Joelle Sarlls, Ph.D.

NIH MRI Research Facility
National Institute of Neurological Disorder and Stroke
National Institutes of Health

# Motivation

- Magnetic resonance imaging provides information about the spatial distribution of water.
- Diffusion-weighted MRI (DWI) provides information about the motion of water.
- DWIs are sensitive to cellular architecture and tissue integrity.
- DWI can provide quantitative measures that are directly comparable.
- Diffusion imaging can be used to identify specific white matter tracts
- ~570 publications combining fMRI and DWI


# **Outline**

- What is diffusion?
- How do we measure diffusion in MRI?
- How do we extract directional information?
- What are the practical problems and limitations?
- Beyond the diffusion tensor

# Outline

- What is diffusion?
- How do we measure diffusion in MRI?
- How do we extract directional information?
- What are the practical problems and limitations?
- Beyond the diffusion tensor

 Diffusion refers to the random translational (Brownian) motion of molecules that results from the thermal energy of theses molecules




$$D = \frac{kT}{6\pi\eta R_H} \quad \text{(for sphere)}$$


Stokes-Einstein

# Gaussian Distribution

 Large number of particles that are free to diffuse have a squared displacement of a Gaussian form



# Diffusion



$$\langle r^2 \rangle \approx 6DT_{dif}$$

$$D \approx 3.0 \times 10^{-3} \ mm^2/s$$

$$T_{dif} \approx 30 \ ms$$

$$r \approx 25 \ \mu m$$

 If the motion of water is hindered by cell membranes, macromolecules, etc. the displacement will be less and D will appear lower.

# **Outline**

- What is diffusion?
- How do we measure diffusion in MRI?
- How do we extract directional information?
- What are the practical problems and limitations?
- Beyond the diffusion tensor

# Image Intensity in MRI


Physical property of tissue water

| - ρ   | proton density                                  | Concentration of water                      |
|---|---|---|
| <ul><li>T1</li><li>T2</li><li>T2*</li></ul> | relaxation time relaxation time relaxation time | Rotational motion,  Magnetic field strength |
| – D   | diffusion coefficient                           | Translational motion                        |

• Experimentally controlled parameters


| <ul><li>Sequence</li></ul> | Spin-echo/gradient echo    |
|----------------------------|----------------------------|
| - TR                       | Time of Repetition         |
| - TE                       | Time to echo               |
| <ul><li>b-value</li></ul>  | diffusion-weighting factor |

#### Gradients make the resonance frequency a function of spatial position



$$\omega = \gamma B = \gamma B_0 + \gamma z G_z$$


# Basic Diffusion-weighting



# Phase Twist




# Basic Diffusion-weighting



# Short Break for a Video


# Spin-echo Diffusion Preparation



$$b = (\gamma G \delta)^2 \left( \Delta - \frac{\delta}{3} \right)$$

Stejskal, EO and Tanner, JE. J Chem Phys (1965) 42: 288-292

# DWI



Non-diffusion-weighted signal intensity

B-value sec/mm<sup>2</sup>

Diffusion
Coefficient
mm²/sec


# Typical DWI


 Single-shot "spin-echo" Echo Planar Imaging


| Parameter       | Value       | Comment            |
|-----------------|-------------|--------------------|
| TE              | 50-100ms    | Limited by b-value |
| TR              | >5s         | Fully relaxed      |
| Matrix          | 96 x 96     | 2.5 x 2.5 mm       |
| Slice Thickness | 2.5 mm      | Equal dimensions   |
| B-value         | ~1000 s/mm² | For brain*         |

\*Jones D., et al. Mag Res Med (1999) 42 : 515


## Calculate Diffusion Parameters








Diffusion map




$$b = 0 \text{ s/mm}^2$$

$$I_0$$



 $b = 1100 \text{ s/mm}^2$  Gz

$$I_z = I_0 e^{-bD_z}$$




Dz


$$D_z = \frac{1}{-b} \ln \left( \frac{I_z}{I_0} \right)$$

# Water Diffusion in Tissue


#### **Not Free**

Cell membranes
Organelles
Extracellular matrix





# Acute Stroke



Warach S., et al. Ann Neurol (1995) 37:231-241


# **Outline**

- What is diffusion?
- How do we measure diffusion in MRI?
- How do we extract directional information?
- What are the practical problems and limitations?
- Beyond the diffusion tensor


# Water Diffusion in Tissue

#### **Not Free**


Cell membranes
Organelles
Extracellular matrix



# Anisotropic Diffusion




# The Diffusion Tensor




$$\underline{D} = \begin{bmatrix} D_{xx} & D_{xy} & D_{xz} \\ D_{yx} & D_{yy} & D_{yz} \\ D_{zx} & D_{zy} & D_{zz} \end{bmatrix}$$

Basser, P, et. al. J Magn Reson B (1994) 3: 247-254


# DTI






 $b = 1100 \text{ s/mm}^2$ 

# Calculate Diffusion Tensor



# Diagonalize DT

$$\underline{D} = \begin{bmatrix} \lambda_1 & 0 & 0 \\ 0 & \lambda_2 & 0 \\ 0 & 0 & \lambda_3 \end{bmatrix}$$



Eigenvalues


Eigenvectors

# **Quantitative Parameters**

$$\underline{D} = \begin{bmatrix} \lambda_1 & 0 & 0 \\ 0 & \lambda_2 & 0 \\ 0 & 0 & \lambda_3 \end{bmatrix}$$

#### **Average Diffusivity**


$$< D> = \frac{\lambda_1 + \lambda_2 + \lambda_3}{3}$$




#### **Fractional Anisotropy**

$$FA = \frac{\sqrt{3(\lambda_1 - \langle \lambda \rangle)^2 + (\lambda_2 - \langle \lambda \rangle)^2 + (\lambda_3 - \langle \lambda \rangle)^2}}{\sqrt{2(\lambda_1^2 + \lambda_2^2 + \lambda_3^2)}}$$


 $0 \le FA \le 1$ 







# Directional Encoding for DTI





Pajevic S. and Pierpaoli C., Magn Reson Med (1999) 43: 526-540

# <D>

# Directional Encoded Color Map







# Applications of DTI

- Cerebral Ischemia (Stroke)
- Brain Cancer and Effects of Radiotherapy
- Multiple Sclerosis
- Epilepsy
- Metabolic Disorders
- Normal Brain Maturation and Aging

- Traumatic Brain Injury
- Alzheimer's Disease
- Amyotrophic Lateral Sclerosis
- Niemann-Pick type C Disease
- Dementias
- Connectivity

## Outline

- What is diffusion?
- How do we measure diffusion in MRI?
- How do we extract directional information?
- What are the practical problems and limitations?
- Beyond the diffusion tensor

# Typical DW SSEPI

#### **PRO**

Insensitive to Bulk motion

Time Efficient


#### CON

Low Resolution


Distortions - Field inhomogeneities

Distortions - Diffusion weighting


# CON: Distortions from field inhomogeneities



T2-weighted FSE




Non-diffusion-weighted SSEPI





SSEPI corrected

### CON: Distortions from DW




DW SSEPI volumes






FA maps



## Other Artifacts







Large Motion

**Cardiac Pulsation** 


Fat (Shifted Image)

## **Outline**

- What is diffusion?
- How do we measure diffusion in MRI?
- How do we extract directional information?
- What are the practical problems and limitations?
- Beyond the diffusion tensor

## What isTractography?

The use of orientation information from diffusion imaging to reconstruct estimates of white matter pathways in the brain.




# Limitation to DTI comes from partial volume effects



Typical resolution for SSEPI DTI 2.5 x 2.5 x 2.5 mm

Cortical projection systems of left cerebral hemisphere


### Partial Volume Effect




## Beyond Standard DTI


- High Angular Resolution Diffusion Imaging (HARDI)
  - Multi-tensor models
  - Non-parametric algorithums
    - DSI, Qball, SD, PAS

## Non-parametric Algorithms





 $b = 0 \text{ s/mm}^2$ 



## ACKNOWLEDGEMENTS

Peter Bandettini, PhD
Carlo Pierpaoli, MD,PhD
Ted Trouard, PhD
Lindsay Walker, MS
Kathy Warren, MD
Emilie Steffen
Dan Handwerker, PhD

#### THANK YOU